FAVI ENTERTAINMENT®
technology + design

© 2013 FAVI ENTERTAINMENT

IMPORTANT SAFETY NOTES

- Do not use speaker in areas where flammable gases or fumes are present.
- Do not expose speaker to water or other sources of moisture. Speaker contains an internal lithium ion battery.
- Do not expose speaker to extreme temperatures. Extreme temperatures will shorten the battery's life span.
- Use only the supplied micro USB charging cable to charge speaker. Using other USB chargers may overcharge the internal battery and shorten the battery's lifespan.
- Do not attempt to disassemble speaker or replace the internal battery. Doing so will void your warranty.

© 2013 FAVI ENTERTAINMENT

TECHNICAL SPECIFICATION

Output Power	2 x 3W
Input Power	DC 5V/500mA Micro USB
Battery Capacity	750mAh Li-ion
Play Time	6 hours
Dimensions	9.92 x 3.7 x 4.09 in
Weight	1.49 lbs

© 2013 FAVI ENTERTAINMENT

FAVI audio+

Wireless Speaker for Tablets

Quick Start Guide

FAVI ENTERTAINMENT®
technology + design

© 2013 FAVI ENTERTAINMENT

FEATURES





© 2013 FAVI ENTERTAINMENT

GETTING STARTED

1. Please fully charge speaker for 2 hours with micro USB cable via computer system or power adapter
2. Turn on Power Switch (rear) to ON position then press ON/OFF Power Button (font)
3. Play music file or app on Tablet
4. Place Tablet Speaker against Set to Connect™ Touchpoint Set to Connect
5. Music from your Tablet should begin playing through audio+ Speaker

Volume Control

Volume can be adjusted directly from your Tablet

Power Status

- Blue Indicator Light (front) = Speaker is ON
- Blue Indicator Light Flashes to Music = Speaker is Playing
- No Blue Indicator Light = Speaker is OFF
- Red Indicator Light = Speaker is Charging

© 2013 FAVI ENTERTAINMENT

WHAT'S IN THE BOX

1x Wireless Speaker
1x Micro USB Charging Cable
1x Quick Start Guide

PRODUCT REGISTRATION

Thank you for purchasing FAVI audio+!

To better serve you, please take a moment to register your product:

www.favientertainment.com/register

Product Registration allows us to send you important updates, service information and helpful hints. It will also make it easier should you ever need to call in for Technical Support. FAVI values your privacy and will never share your information with other companies.

© 2013 FAVI ENTERTAINMENT

TROUBLESHOOTING

Issue: *I can't connect my tablet.*

Try: Check the power switch in back is turned to ON position. Then click front power button until Blue indicator light is solid. Play a music file or app from the tablet. The tablet speaker should be touching the Set to Connect™ touchpoint logo. The blue indicator light will flash to the music when you're connected successfully.

© 2013 FAVI ENTERTAINMENT